

### Product Contents

- Motion Detection Sensor
- HiSAVER Surge Protector
- Magnetic Placement Plate & Stickers (2pcs) for Motion Detection Sensor
- Quick Start Guide

**DO NOT USE**

- Hospitals for Life Care Machines
- Industrial Machines
- Nuclear Power Stations

**CALL TO ACTION :**  
 For warranty service, please contact our customer service at 00 800 8010 8012 or E-mail at [CShisaver@hanaro.eu](mailto:CShisaver@hanaro.eu)  
 If you have problem, you need to go to see and/or download the full owner's Manual from the web site. [www.hisaver.com](http://www.hisaver.com)

[www.hisaver.com](http://www.hisaver.com)

## Quick Start Guide

for TV / Audio Home Entertainment System

**HiSAVER™**  
Energy Saving

### For TV / Audio Home Entertainment System Use / Installation

- 1** Plug the HiSAVER Surge Protector into a wall outlet.
- 2** Place the Motion Detection Sensor on the TV or audio equipment. The sensor is attached to the back of the device using the provided magnetic plate and stickers.

- 3** Plug the HiSAVER Surge Protector into a wall outlet. The sensor is always ON. It is also shown connected to a Satellite Receiver or Settop Box.

Always ON

Satellite Receiver or Settop Box

### HiSAVER™ Energy Saving Steps

**ON** **OFF**

**1** 5 watts

**2** 350 watts

**NOTE** Always ON: Satellite Receiver or Settop Box

**!** The amount of Watt can vary by using different devices.

- 3** 5 watts
- 4** 350 watts

After Setting Time on Sensor

Will be turned OFF

They will turn back ON if you have not switched them OFF manually.

- 4** TV / MONITOR, VCR, DVD, GAME, Receiver
- 5** TV / MONITOR, VCR, DVD, GAME, Receiver

### Motion Detection Sensor Time Selector Button

- 1 Hour
- 2 Hours
- 3 Hours
- Always ON (No LED Light)

**NOTE** Always ON : HiSAVER™ will NOT automatically turn off power to your all devices.