


# Compact multilanguage owner's manual

**Model One**

**TIVOLI**  
**AUDIO**™




**1. VOLUME:** Turn the volume knob to the right to increase the volume or to the left to decrease the volume of the Model One's speakers. This knob will also control the volume of headphones when connected.

**2. POWER LIGHT:** Glows green when the unit is active.

**3. TUNING INDICATOR:** The tuning indicator will appear brightest when best tuning has been achieved. Some weak, but listenable AM stations will not light the tuning indicator and should be tuned for loudest and clearest signal.

**4. OFF/FM/AM:** Turn the knob 1 click to the right to select the FM band, 2 clicks to the right to select the AM band. Turn the knob to the left to turn off the Model.

**5. TUNING:** Turn the tuning knob to the right or to the left to change the frequency range.



## WARNING

1. For your safety, keep the Model One a safe distance away from a naked flame, such as a lit candle.
2. The recommended operating temperature range for the Model One is 5 degrees C - 40 degrees C.
3. The 12-16VDC input is suited for operating the Model One in a boat or camper using an optional 12VDC, 1A fused adaptor.

**1. ANTENNA SWITCH:** Switch between internal and external FM antennae. This switch has no effect on AM reception.

**2. 12-16VDC:** Use this input to operate the Model One from a DC power supply.


**3. REC OUT:** The Model One can be used as a separate tuner by going from the record out to an amplifier. You may also record in mono by using the output.

**4. HEADPHONE:** Connect a separate headset jack to this connector to listen to the Model One with a headset. Inserting headset will turn off main speaker.

**5. AUX IN:** Connect a stereo or mono audio source (like a CD player or a TV) to this stereo input.

**6. EXTERNAL ANTENNA:** The Model One comes with built in AM/FM antennas. To improve FM reception, insert the end of the supplied wire antenna into the center of this "F" connector. Adjust the wire for best reception. A 75-ohm coaxial cable or outdoor antenna may also be attached to this connector.





1. Wahlschalter zur Selektion zwischen der internen Antenne und der externen Antenne.
2. Benutzen Sie diesen Eingang zum Anschluß eines Gls-Netzgeräts.
3. Das Gerät kann als separater Tuner eingesetzt werden, indem Sie an die Buchse "Rec out" einen Verstärker anschließen. Die Buchse kann auch als Eingang für Mono-Aufzeichnungen benutzt werden.
4. Stereoausgang zum Anschluß eines Kopfhörers. Bei Anschluß eines Kopfhörers wird der Lautsprecher des Geräts automatisch abgeschaltet.
5. Stereoeingang zum Anschluß einer Stereo- oder Monoquelle (CD-Player, Fernseher, u.a.).
6. Das Gerät ist mit einer internen FM- und AM-Antennen ausgestattet. Um den FM-Empfang zu verbessern, können Sie das Ende der zum Gerät gehörenden Wurfantenne an die Klemme "F" anschließen. Legen Sie die Wurfantenne anschließend so aus, daß ein optimaler Empfang gewährleistet ist. An diese Klemme kann des weiteren ein 75-Ohm-Koaxialkabel oder eine Außenantenne angeschlossen werden.

For warranty and information outside of USA please contact your local distributor:  
<http://www.tivoliaudio.com>